

DSK-OPBM002

This Wire Set can not be used without the Main Unit of DSPARK MAX sold separately.

Wiring Illustration



Typical Application	CC	Car Model	Engine Model	Production Year/Month
320i (E46)	2200	GF-AV22	226S	'02 10~'05 3
323i (E90)	2500	ABA-VB23	N52B25A	'05 4~
325i (E46)	2500	GH-AV25	256S	'02 10~'05 3
325i (E90)	2500	ABA-VB25	N54B25A	'05 4~
335i (E90)	3000	ABA-VB35	N54B30A	'06 1~

Some other car models may be applicable. Please check with Application Table for details.

- Take off the battery terminals of both Plus and Minus. Then remove the engine head cover and any other obstacle part for taking off the Ignition Coils.



② Fitting of Coil Harness

- Take off the original coupler from the coil.
- Pull out the Ignition Coils from plug hole.



CAUTION

In order to pull out the coil, hold the coil head and do not hold the harness for pulling out the coil. It will damage the harness if the coil is pulled out without taking off the coupler.

※The grounding wire for coil is not necessary for this car model because of the system.

- Connect the Wire Set in between the coils and original coupler.
- Please take the same steps for six coils.



- After fixing the specific Wire Set with coils, the remaining coupler of wire set to be connected with the Main Unit. Connection of the wire set with the Main Unit is as shown in the installation manual of DSPARK MAX Main Unit sold separately.

DSK-OPBM002 BMW 宝马

